

Pressure Washer Safety





Keeping equipment and facilities clean helps with maintenance, performance, and aesthetics. Despite the benefits, pressure washers can cause serious injury if not operated correctly.

Before using a pressure washer, learn how to properly operate it.

Before Operating

- Read the manufacturer's operating manual prior to use.
- Know how to use and maintain the power washer.
- Protect yourself from carbon monoxide poisoning by only starting and running a gaspowered unit outside and ensuring proper ventilation during operation.
- Wear appropriate personal protective equipment:
 - Safety glasses or goggles or a face shield (with safety glasses or goggles).
 - Enclosed footwear with good traction (preferably waterproof).
 - Hearing protection (gas-powered units).

- Protective clothing (long pants, waterproof top and bottom)
- \circ Gloves with good dexterity.

Power Washing Safety Tips

- Maintain a minimum 6-ft. distance when spraying water around power lines, electrical masts, or outlets.
- Engage the safety lock on the trigger when you are not washing and turn off when changing nozzle tips.
- Before uncoupling hoses, stop the machine, turn the water off and squeeze the spray wand trigger to release all water pressure in the system.
- Remain aware of your surroundings for any changes that may turn hazardous.
- Do not hold the spray tip closer than 12inches to a surface.
- Do not point the pressure washer at people, animals or put any body part in front of the nozzle. The pressurized water stream could penetrate your skin and cause serious injury.
- Do not use pressure washers while working from ladders or elevated surfaces.